

HOME DECORATORS C O L L E C T I O N


BF-25180 MARTHA STEWART LIVING KIDS CRAFT 33" WIDE
OPEN STORAGE 25"Hx33"Wx15"D

INV#19040

ASSEMBLY INSTRUCTIONS













Made In China

THIS ITEM MUST BE ASSEMBLED BY AN ADULT




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST		
A  TOP PANEL-1PC	B  LEFT SIDE PANEL-1PC	C  RIGHT SIDE PANEL-1PC
D  STAND PANEL-1PC	E  ADORNING PANEL-1PC	F  BOTTOM PANEL-1PC
G  UP BACK PANEL-1PC	H  DOWN BACK PANEL-1PC	I  SHELVES-4PCS
J  CAM-BOLTS-28PCS	K  CAM-LOCKS-28PCS	L  FEET-4PCS


M



SHELF SUPPORTS-16PCS

N

8mm × 1 "



SCREWS-2PCS


O



CAM-T00L-1PC

P



6mm × 1/2 "



SCREWS-16PCS



NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1). ASSEMBLE THE BACK PANEL (H/G).

- ROTATE 3 CAM-BOLTS (J) INTO THE HOLES IN THE UP BACK PANEL (G).
- PLACE CAM-BOLTS (J) INTO THE HOLES IN THE DOWN BACK PANEL (H) AND ATTACH USING 3 CAM-LOCKS (K).




2). ASSEMBLE THE BOTTOM PANEL (F).

- ROTATE 2 CAM-BOLTS (J) INTO THE HOLES IN THE BOTTOM PANEL (F).
- PLACE CAM-BOLTS (J) INTO THE HOLES IN THE STAND PANEL (D) AND ATTACH USING 2 CAM-LOCKS (K).




3). ASSEMBLE THE BOTTOM PANEL(F).

- ROTATE 3 CAM-BOLTS(J) INTO THE HOLES IN THE DOWN BACK PANEL(H).
- PLACE CAM-BOLTS(J) INTO THE HOLES IN THE BOTTOM PANEL(F) AND ATTACH USING 3 CAM-LOCKS(K).




4). ASSEMBLE THE LEFT SIDE PANEL(B).

- ROTATE 6 CAM-BOLTS(J) INTO THE HOLES IN THE LEFT SIDE PANEL(B).
- PLACE CAM-BOLTS(J) INTO THE HOLES IN THE PANEL(H/G/F) AND ATTACH USING 6 CAM-LOCKS(K).




5). ASSEMBLE THE RIGHT SIDE PANEL(C).

- ROTATE 6 CAM-BOLTS(J) INTO THE HOLES IN THE RIGHT SIDE PANEL(C).
- PLACE CAM-BOLTS(J) INTO THE HOLES IN THE PANEL(H/G/F) AND ATTACH USING 6 CAM-LOCKS (K).




6). ASSEMBLE THE FEET(L).

- ROTATE 4 FEET(L) INTO THE HOLE IN THE PANEL(B/C).




7). ASSEMBLE THE TOP PANEL (A).

- ROTATE 8 CAM-BOLTS (J) INTO THE HOLES IN THE TOP PANEL (A).
- PLACE CAM-BOLTS (J) INTO THE HOLES IN THE PANEL (B/C/D/G) AND ATTACH USING 8 CAM-LOCKS (K).




8). ASSEMBLE THE ADORNING PANEL (E).

- ATTACH THE ADORNING PANEL (D) TO TOP PANEL (A) USING 2 SCREWS (N).



9). ASSEMBLE THE SHELF SUPPORTS (M).

- INSERT 16 SHELF SUPPORTS (M) INTO THE HOLES IN THE PANEL (B/C/D).



10). ASSEMBLE THE SHELVES (I).

- ATTACH THE SHELVES (I) TO SHELF SUPPORTS (M) USING 16 SCREWS (P).